



Installation

Mechanical safe can be fixed to the wall and to the floor opening the pre-drilled holes on the bottom and on the rear.

N.B.: to wall and floor fixing we suggest you to use dowels with screw diameter of 8 mm. Floor and wall should have proper pull dowels resistant.

How to replace the cylinder

- **With door opened**, turn the key anticlockwise making lockbolts come completely out.
- Remove the key.
- Unscrew the screw " A " and remove the top " B " .
- Unscrew the screws situated on the safe door back cover as per point " C " and unthread the security escutcheon " D " .
- Insert the key directly into the cylinder.
- Unscrew screw " E " situated on the safe door back cover.
- Turn the key slightly and pull the cylinder until it can be unlocked and therefore removed.
- Replace with a new cylinder * complete with key. Then turn the key gently while pressing the cylinder up to the end
- Screw the screw " E " .
- To check if cylinder works correctly, **open the door** and turn the key clockwise and anticlockwise to make lockbolts come in and out.
- WARNING: Possible problems in the key rotation are due to an incorrect alignment of the cylinder into its housing. To solve them, it would be necessary to unscrew the screw " C " and put the cylinder in a correct position.**
- Remove the key.
- Put the security escutcheon back into the cylinder. **N.B.:** Movable ring " F " should be positioned as per.
- Screw all " C " screws while keeping security escutcheon blocked in its position.
- To check if cylinder works correctly, **open the door**, insert the key and check if it turns without encountering frictions.
- WARNING: Possible problems in the key rotation are due to an incorrect alignment of security escutcheon. To solve them, it would be necessary to unscrew all " C " screws and to refit them into the correct position.**

Warranty conditions and contents

All Viro products undergo the most stringent testing and therefore guarantee reliability. Viro SpA reserves the right to introduce modifications or improvements to its products, which may deem desirable without obligating itself to install such improvements to its previously manufactured safes. Viro SpA guarantee their products to be free from defects in material and manufacturing for the period provided for by effective law on purchasing time (Decr. Leg. 2/02/02 n.24 that puts into effect Directive No 1099/44/CE) and will replace or repair at no charge all component parts of the product under warranty - after consultation with our technical department or an authorised Service Centre - should they be defective due to a manufacturing or material flaw. The warranty covers the replacement of the components, ex-works, if defective, but does not include the safe opening costs, the removing costs and the final replacement, or any other cost or damage, even though related to the defective product. The property damage responsibility of Viro SpA will be in no case higher than the selling price of the article itself, even if the damage - including the content of the safe - is due to forcing, theft or burglary. The warranty shall not apply to any Viro component part which has been subject to misuse, neglect, incorrect installation of maintenance, or to a use in contravention of instructions furnished by the Company. The warranty does not extend to safes which have been installed in unsuitable environments or which have been repaired by unauthorised personnel or suffered damage in transit, or to any other circumstance not ascribable to faults in manufacture. Viro SpA shall not be liable for any direct, indirect and consequential damage and/or injury arising from the malfunctioning of their product or from the safes, or if caused by negligence or by lack of compliance with the instructions manual. The warranty shall take effect from the date of purchase. Sales receipt (fiscal receipt, cash-desk receipt, invoice, delivery note or the like) validates the date of purchase, irrespective of the actual fitting date. Failing a sales receipt, the warranty shall be calculated from the date of manufacture of the product, which shall be determined from its serial number. In case of purchasing of safe/cabinet supplied complete with external contacts for the emergency opening (without mechanical emergency opening), should the safe not be open due to its block or malfunctioning, Viro S.p.A. is free from any responsibility for damages caused to things or persons, even if connected or depending to the malfunctioning, including the content of the safe. The Seller is completely excluded from any costs and charges for forced opening of the safes/cabinets, their removal and further new installation of the product and the restoration of the places conditions.